









Spare Parts list

Part Description	RW25	RW45	
Pump Assembly	R35228	R35229	
Controller	R35230	R35241	
Power Supply	R35231	R35242	
Motor assembly	R35232	R35243	
Rotor (shaft/magnet)	R35233	R35244	
Impeller set	R35234	R35245	
Impeller Cage set	R35235	R35246	
Mounting Bracket	R35236	R35247	

Part Description	RW25	RW45	
Internal magnet set	R35237	R35248	
External magnet	R35238	R35249	
End Cap & O-ring set	R35239	R35250	
Snail Guards (4 units)	R35240	R35251	
Controller Mounting Bracket	R35252		
RW 25/45 Pump Extension cable 2m/79"	R35253		
RW Pump Service Pack	R35254	R35255	