

RMS Tank Mount System Mounting Instructions for Radion XR30 and XR15 LED Models









Kit Assembly Instructions

1. Choose appropriate Spacer configuration



- 2a. If using the RMS on a rimmed tank; leave the included spacer on the clamp chop.
- 2b. If using the RMS on a rimless tank; slide the included spacer off of the clamp chop.

2. Mount RMS assembly to tank
WARNING: Do not over tighten clamp, over-tightening
may result in damage to your tank or RMS assembly.




3. Choose appropriate Sliding Rail for desired front to back position

*XR15 Kit only includes two Sliding Rails.



- 4. Insert X-Bracket assembly into the end of the Sliding Rail and tighten down screws
 - 2 1 1 (XR15)
- 5. Attach Radion to X-Bracket



6. Guide Sliding Rail onto Formed Arm over the locking nut and tighten screw in desired position

